

ReadMe file for firmware version 1.34 of the
KODAK PROFESSIONAL RFS 3600 Film Scanner
File name - 3600_134.bin

March 2002

This firmware supports the following:

KODAK PROFESSIONAL RFS 3600 Film Scanner.

The following information is available in this ReadMe file:

- 1.1 NOTE TO USERS UPGRADING TO VERSION 1.34
- 1.2 WHAT'S NEW IN THIS VERSION
- 1.3 COMPATIBLE RFS 3600 FILM SCANNER HOST SOFTWARE
- 1.4 KNOWN ISSUES
- 1.5 FIRMWARE INSTALLATION INSTRUCTIONS
- 1.6 SCANNER FIRMWARE IS AVAILABLE ON THE WORLD WIDE WEB

1.1 Note to users upgrading to version 1.34

Follow the installation instructions in this file for a successful upgrade operation.

1.2 What's new in this version

When firmware version 1.34 is used with RFS 3600 Host Software version 2.10, you will have a variety of new film scanner features. Review the RFS 3600 Film Scanner User's Manual Addendum, available on www.kodak.com, to learn about the new features.

1.3 Compatible RFS 3600 Film Scanner Host Software

Version 1.34 firmware should be used with KODAK PROFESSIONAL RFS 3600 Film Scanner Acquire Module or KODAK PROFESSIONAL RFS 3600 Film Scanner TWAIN Data Source Version 2.10 or higher.

1.4 Known Issues

None

1.5 Firmware Installation Instructions

The RFS 3600 Film Scanner firmware must be installed using the RFS 3600 Film Scanner Host Software.

Important: Once the upgrade process is running, do not:

- Disconnect power from the RFS 3600 Film Scanner
- Insert a slide or filmstrip
- Attempt to abort the upgrade process
- Use your computer to work on other tasks

For installation, follow these steps:

1. Download the firmware file 3600_134.bin to your computer, saving the file to a location you can access.
2. Ensure you have a version of the RFS 3600 host software installed - Use the TWAIN Data Source for Windows machines, or the Photoshop Acquire Module for Macintosh machines.
3. Connect your film scanner to your computer as described in the User's Manual.
4. Turn on the computer and film scanner.
5. Start the RFS 3600 Film Scanner Host Software (for example, the Acquire Module or TWAIN Data Source) and verify that the software finds the film scanner.
6. Click on the About icon (Version 1.xx software) or the Information icon (Version 2.10 software).
7. When the About screen appears, click on the Upgrade button. In the Open dialog box, navigate to the location you saved the

firmware file 3600_134.bin. Select the file 3600_134.bin, click Open and the firmware upgrade procedure will begin. When the upgrade is almost complete, you will hear your RFS 3600 Film Scanner "reboot".

8. Exit from the Host Software when directed to do so.

9. Restart the Host Software.

10. Click on the About or Information icon and verify the firmware version listed is 1.34.

11. If you do not have Host Software version 2.10 installed, install it NOW! You may obtain this software as a free download from www.kodak.com. Do not use your updated film scanner with older host software (Version 1.00, 1.10 or 1.20).

1.6 As new film scanner firmware is made available, its download file is placed on the World Wide Web (WWW). To check whether a new firmware download version is available for your film scanner, use the following URL path:

<http://www.kodak.com/go/drivers>

For additional information read the RFS 3600 Film Scanner Host Software ReadMe file (either RFS 3600 Acquire Module or RFS 3600 TWAIN Data Source) which is available at www.kodak.com.

All trademarks and product names mentioned in this ReadMe are the property of their respective owners.